PRS-FIN, PRS-FINNA and PRS-FINS Fiber Interfaces

www.boschsecurity.com





- ▶ Redundant network connection
- ▶ Indicators for power and fault status
- ► Two supervised control inputs (not PRS-FINNA)
- ► Can use a local power supply

Most of the Praesideo system units have plastic fiber optic interfaces. Plastic fiber is used to interconnect nodes which are less than 50 meters apart. For distances of more than 50 meters, glass fiber optic cable is used. A fiber interface converts from plastic to glass fiber, and vice versa. The fiber interfaces have a power supply input to provide power to remote network sections, and two control inputs. The control inputs can pass on supervision information about the power supply connected to the fiber interface.

Functions

These units interface glass fiber optical cable with plastic fiber optical cable, and support redundant wiring topology. In many applications this is necessary, because glass fiber can bridge much longer distances than plastic fiber. Any conversion to glass fiber must be converted back to plastic fiber before other Praesideo units can be attached, since they all have plastic fiber interfaces. This means that these units are always used in pairs.

Each interface can use an external 48 VDC power supply to provide power for itself, as well as for remote parts of the network. If there is no external power source, the interface uses power from the

network controller. The PRS-FIN and PRS-FINS have two control inputs. These can be used to accept e.g. the fault output of the external power supply (UPS), allowing the units to monitor the power supply and report faults to the network controller. The fiber interfaces have two LEDs for diagnostic purposes.

The PRS-FINNA is the same as the PRS-FIN except that it has no network node address. This has the advantage that the unit does not occupy one of the 60 possible addresses in the network. It also has the disadvantage that without an address, it is not possible to access the status of the two control inputs, as it is with the PRS-FIN.

The PRS-FINS is the same as the PRS-FIN, except that it accepts single-mode glass optical fiber instead of multi-mode glass optical fiber. However, this does not increase the maximum permitted cable length of a Praesideo network.

Controls and indicators

- Power status LED
- · Network status LED

Interconnections

- Network connection for plastic optical fiber
- · Network connection for glass optical fiber
- External power supply input
- Two control inputs (not PRS-FINNA)

Certifications and approvals

Safety	acc. to IEC 60065 / EN 60065
Immunity	acc. to EN 55103-2 / EN 50130-4 / EN 50121-4
Emissions	acc. to EN 55103-1 / FCC-47 part 15B
Emergency	acc. to EN 60849 / EN 54-16 / ISO 7240-16
Maritime	acc. to IEC 60945

Region	Certification	
Europe	CPR	EU_CPR
	CE	COC
	CE	CertAlarm
	CE	

Installation/configuration notes

The PRS-FINNA and the PRS-FIN are often used in combination. The PRS-FINNA is placed in the local (POF) network, and connected to a (remote) PRS-FIN, which can then provide remote monitoring. The PRS-FINS is mostly used in installations where single-mode (mono-mode) glass fiber is already present. Otherwise multi-mode glass fiber is a cheaper alternative.

Parts included

Quantit y	Component
1	PRS-FIN Fiber Interface or PRS-FINNA Fiber Interface Non-Addressable or PRS-FINS Fiber Interface Single Mode
1	Mounting bracket
1	Control input connector
1	Power supply connector

Technical specifications

Electrical

Power consumption	4.6 W (DC)
External power supply	
Voltage	24 to 56 VDC, 48 VDC nominal
Current	2.5 A maximum (5 A peak <2 s)

2 x
Screw terminals
Closing contact (with supervision)
SC (Avago AFBR-5803Z transceiver)
SC (Avago AFCT-5805BZ transceiver)
1300 nm
62.5/125 μm or 50/125 μm multi-mode
9/125 μm single-mode

Mechanical

Dimensions (H x W x D)	
Without bracket	27 x 243 x 80 mm (1.1 x 9.6 x 3.1 in)
With bracket	34 x 243 x 84 mm (1.3 x 9.6 x 3.3 in)
Weight	0.7 kg (1.5 lb)
Mounting	Bracket (2 screws)
Color	Charcoal

Environmental

Operating temperature	-5 °C to +55 °C (+23 °F to +131 °F)
Storage temperature	-20 °C to +70 °C (-4 °F to +158 °F)
Humidity	15% to 90%
Air pressure	600 to 1100 hPa

Ordering information

PRS-FIN Fiber Interface

Compact unit with mounting clamp, interface between Praesideo network and a multi-mode glass fiber interconnection to a second fiber interface, powered from Praesideo network.

Order number PRS-FIN

PRS-FINNA Fiber Interface Non-Addressable

Compact unit with mounting clamp, non-addressable interface between Praesideo network and a multimode glass fiber interconnection to a second fiber interface, powered from Praesideo network.

Order number PRS-FINNA

PRS-FINS Fiber Interface Single Mode

Compact unit with mounting clamp, interface between the Praesideo network and a single-mode glass fiber interconnection to a second fiber interface, powered from the Praesideo network.

Order number PRS-FINS

Represented by:

Americas:

Americas: Bosch Security Systems, Inc. 12000 Portland Avenue South Burnsville MN 55337, USA Phone: +1-800-392-3497 Fax: +1-800-955-6831 audiosupport@us.bosch.com www.boschsecurity.com

Europe, Middle East, Africa:

Bosch Security Systems B.V. P.O. Box 80002 P.O. Box 80002 5617 BA Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

Asia-Pacific:

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security
Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
apr.securitysystems@bosch.com
www.boschsecurity.asia

China:

China:
Bosch (Shanghai) Security Systems Ltd.
201 Building, No. 333 Fuquan Road
North IBP
Changning District, Shanghai
200335 China
Phone +86 21 22181111
Fax: +86 21 22182398 www.boschsecurity.com.cn

America Latina:

America Latina:
Robert Bosch Ltda Security Systems Division
Via Anhanguera, Km 98
CEP 13065-900
Campinas, Sao Paulo, Brazil
Phone: +55 19 2103 2860
Fax: +55 19 2103 2862
latam.boschsecurity@bosch.com
www.boschsecurity.com