


























# LED INDICATION / LED INDIKERING

SAC-U32

## LED INDICATORS

LED indicator		Status
Green/Grön	Red/Röd	ENG/ SE
		Main power supply / Nätdrift
		Power failure - Emergency-light-operate / Strömavbrott - Nödljus
		Function test / Funktionstest
		Emergency duration test / Driftvaraktighetstest
		Emergency duration <2h / Driftvaraktighetstest <2h
		Illuminant - Charge over defekt / Ljuskälla - omkoppling defekt
		Battery - Charge defect / Batteri - Laddning defekt

## MANUAL TEST FUNCTION

TEST button	LED	Status
Press _sec	Green/Grön	ENG/ SE
		Main power supply/ Nätdrift
		A short time emergency operation 5sec/ Kortvarig nöddrift 5sek
		Start function test emergency operation 30sec/ Funktionstest 30sek
		Start emergency duration test 3h/ Driftvarighetstest 3h
		Stop emergency duration test/ Driftvarighetstest avbryts

ENG

### Autotest

Once the unit is powered up it will automatically initiate a self test as follows:

**Every week :** Performs a 30 sec duration test

**Every year :** Performs a 3h duration test

SE

### Autotest

Efter anslutning till nätspänningen aktiveras självtestet enligt nedan:

**Varje vecka:** Utförs ett 30 sec långt test

**Varje år:** Utförs ett 3h test


Explanation/ Teckenförklaring			
			
Off Släckt	On Lyser	Flashing Blinkar	Flashing 1/sec Blinkar 1/sec

SAC Nordic AB reserverar sig för eventuella faktura- eller tryckfel i denna trycksak. SAC2017-1

# MANUAL

## SAC-U32

SAC-U32 73 505 51



# SAC-U32

Dubbelsidig hänvisningsarmatur



SAC Nordic AB • Prästtorpsvägen 16 • S-341 51 Lagan • SWEDEN • www.sacnordic.com

Safe Security Solutions





# EMERGENCY LIGHT

SAC-U32 & SAC-U40

ENG

## EMERGENCY LIGHTING

LED 32m / 40m

SAC-U32 are a reference fixture with bright LED's and long life burn time. Low energy, low maintenance and long life combined with a auto-testing system and a modern reliable technology allows the fixture to a choice for simplicity, safety and future. Complies with EN 60598-2-22.

The SAC-U40 consists of a panel (Dimensions: 350 x 242 mm) and 4 pictograms in the most common designs. U40 is an upgrade kit for SAC-U32. The reading distance is 40 m.

- Pictograms (interchangeable) for the most common configurations (included)
- Can be installed on ceiling-, wall- and end-/flag-mounting (included)
- Supervised by a self-testing system
- House of aluminium and acrylic glass
- Battery backup (up to 3 hours emergency operation)
- Maintained or non-maintained
- Accessories: Pendant for ceiling (adjustable 1.5m), Shock protection, battery, pictogram.

SE


## NÖDBELYSNINGSSARMATUR

LED 32m / 40m

SAC-U32 är en enkel- /dubbelsidig hänvisningsarmatur med starka lysdioder och lång brinntid. Låg energiförbrukning, låga underhållskostnader och lång livslängd kombinerat med ett autotestande system och en tillförlitlig teknik gör armaturen till ett val för enkelhet, säkerhet och framtid. Uppfyller kraven enligt EN 60598-2-22.

SAC-U40 består av en plexiglasskiva (Mått: 350 x 242 mm) och 4 st piktogram i de vanligaste utföranden. U40 är ett uppgraderings-kit till SAC-U32. Läsavståndet är 40 m.

- Medföljer utbytbara piktogram för de vanligaste utföranden (Pil höger, vänster och ner)
- Kan monteras på tak, vägg, sida s.k. flaggmontering (medföljer)
- Övervakad med ett självtestande system
- Aluminiumhus och akrylglas
- Inbyggd batteri backup (upp till 3 tim nöddrift)
- Permanentdrift eller nöddrift
- Tillbehör: Takpendelupphängning justerbar 1,5m, bollskydd, batteri, piktogram.



Art.no	E-no	Model	Light source	Viewing distance	Class	Battery backup	Battery Weight	
460401	73 505 50	SAC-U25	15 LED	25 m	IP40	NiMH 4,8V 0,8 Ah 3 h	1,0 kg	
460402	73 505 51	SAC-U32	15 LED	32 m	IP40	NiMH 4,8V 0,8 Ah 3 h	1,3 kg	
460424	73 416 15	SAC-U40	-	40 m	-	-	0,7 kg	
460415	73 513 44	Pendant for ceiling / Takpendel						
460426	73 513 46	(U32) Disabled pictogram / Piktogram rullstol						
460412	73 513 50	Shock protection cover / Bollskydd						
460476	-	Battery pack / Batteripack						





Pictogram





Protection/ Bollskydd

# INSTALLATION & LED / BATTERY REPLACEMENT



SAC-U32



## BATTERY REPLACEMENT / BATTERIBYTE



## LED-STRIP REPLACEMENT / LED-LIST BYTE



ENG

1. Loosen the screw on the side. The side where the LEDs are not!
2. Slide the cover to the side
3. Unplug the battery (carefully!)
4. Loosen the screws on the battery compartment and replace the battery.
5. Carefully pull the LED bar from the slot.
6. Follow the above steps in reverse order.

SE

1. Lossa skruven på sidan. Den sidan där inte lysdioderna sitter!
2. Skjut luckan åt sidan
3. Dra ut kontakten till batteriet (försiktigt!)
4. Lossa skruvarna till batterihållaren och byt batteriet.
5. Dra försiktigt ut LED-skenan ur skåran.
6. Följ stegen ovan i omvänd ordning.