

AuraLoop

Designed for accessibility for all, this hybrid product integrates the magnetic loop and Auracast™ protocol for the first time. Based on this new technology, we're creating unique usage functionalities that will meet all needs over the next few years. Auraloop is the future of accessibility.



AUDIO INPUT

Integrated microphone	Capsule microphone
Microphone plug	1x Jack 3,5 mm

AUDIO OUTPUT

Headphone plug	1x Jack 3,5 mm
Bluetooth transmit power	3 dbm

POWER SUPPLY

Voltage / Current	5-12V DC / 3A
Connector	USB Type C
Battery	3.7V lithium-Ion / 4000mAh
Autonomy	10 hours; 5 hours in use
Charging time	4 hours

CONNECTIVITY

Connectivity #1	Auracast™ (Bluetooth 5.2 +) - 2400 to 2480 MHz
Connectivity #2	Induction Loop
Qualification	Bluetooth SIG
Update	Wireless via AuraConnect application

AUDIO

Sampling frequencies	16 kHz
Codec used	LC3
Connection	Via QR code or password
Automatic Gain Control (AGC)	Yes

TECHNICAL SPECIFICATIONS

Magnetic loop range	1.5 m
Auracast™ range field	2.5 m (open field)
On-board memory	8 Mo

PRODUCT SPECIFICATIONS

Dimensions (L x W x D)	250 x 185 x 80 mm
Weight	366 g

INSTALLATION

AuraLoop is a true plug-and-play system: simply place it at an appropriate distance between you and your interlocutor. Thanks to its mounting base, AuraLoop can also be permanently installed at a workstation.

USE

Powered either by mains electricity or its built-in battery, AuraLoop is perfectly suited for both fixed and mobile use.

Simply press the power button located on the rear of the device and AuraLoop is ready to use. For an optimal user experience, connect the OP-M81 gooseneck microphone and the OP-E3 handset included in the AuraLoop+ kit.

Back view

