PRS-FIN, PRS-FINNA and PRS-FINS Fiber Interfaces

www.boschsecurity.com





Most of the Praesideo system units have plastic fiber optic interfaces. Plastic fiber is used to interconnect nodes which are less than 50 meters apart. For distances of more than 50 meters, glass fiber optic cable is used. A fiber interface converts from plastic to glass fiber, and vice versa. The fiber interfaces have a power supply input to provide power to remote network sections, and two control inputs. The control inputs can pass on supervision information about the power supply connected to the fiber interface.

Functions

These units interface glass fiber optical cable with plastic fiber optical cable, and support redundant wiring topology. In many applications this is necessary, because glass fiber can bridge much longer distances than plastic fiber. Any conversion to glass fiber must be converted back to plastic fiber before other Praesideo units can be attached, since they all have plastic fiber interfaces. This means that these units are always used in pairs.

Each interface can use an external 48 VDC power supply to provide power for itself, as well as for remote parts of the network. If there is no external power source, the interface uses power from the

- Redundant network connection
- Indicators for power and fault status
- Two supervised control inputs
- Can use a local power supply

network controller. The PRS-FIN and PRS-FINS have two control inputs. These can be used to accept e.g. the fault output of the external power supply (UPS), allowing the units to monitor the power supply and report faults to the network controller. The fiber interfaces have two LEDs for diagnostic purposes. The PRS-FINNA is the same as the PRS-FIN except that it has no network node address. This has the advantage that the unit does not occupy one of the 60 possible addresses in the network. It also has the disadvantage that without an address, it is not possible to access the status of the two control inputs, as it is with the PRS-FIN.

The PRS-FINS is the same as the PRS-FIN, except that it accepts single-mode glass optical fiber instead of multi-mode glass optical fiber. However, this does not increase the maximum permitted cable length of a Praesideo network.

Controls and indicators

- Power status LED
- Network status LED

Interconnections

- · Network connection for plastic optical fiber
- Network connection for glass optical fiber
- External power supply input

Two control inputs (not PRS-FINNA)

Certifications and approvals

| Immunity Emissions Emergency Maritime | | acc. to EN 55103-2 / EN 50130-4 / EN 50121-4 | |
|--|---------------------------------|---|--|
| | | acc. to EN 55103-1 / FCC-47 part 15B | |
| | | acc. to EN 54-16 / ISO 7240-16 | |
| | | acc. to IEC 60945 | |
| | | | |
| | | | |
| Region | Regula | tory compliance/quality marks | |
| Region Europe | Regula CPR | tory compliance/quality marks | |
| Region Europe | Regula CPR CE | tory compliance/quality marks EU CPR Telefication COC | |
| Region Europe | Regula CPR CE CE | tory compliance/quality marks EU CPR Telefication COC CertAlarm | |
| Region Europe | Regula CPR CE CE CE | tory compliance/quality marks EU CPR Telefication COC CertAlarm DECL_CE_PRS-FIN | |

Installation/configuration notes

The PRS-FINNA and the PRS-FIN are often used in combination. The PRS-FINNA is placed in the local (POF) network, and connected to a (remote) PRS-FIN, which can then provide remote monitoring. The PRS-FINS is mostly used in installations where single-mode (mono-mode) glass fiber is already present. Otherwise multi-mode glass fiber is a cheaper alternative.

Technical specifications

Electrical

| Power consumption | 4.6 W (DC) |
|-----------------------------------|------------------------------------|
| External power supply | |
| Voltage | 24 to 56 VDC, 48 VDC nominal |
| Current | 2.5 A maximum (5 A peak <2 s) |
| Control inputs | 2 x |
| Connector | Screw terminals |
| Operation | Closing contact (with supervision) |
| Glass optical fiber interface | |
| Connector (PRS-FIN and PRS-FINNA) | SC (Avago AFBR-5803Z transceiver) |
| Connector (PRS-FINS) | SC (Avago AFCT-5805BZ transceiver) |
| Wavelength | 1300 nm |

| Cable type (PRS-FIN and PRS-FINNA) | 62.5/125 μm or 50/125 μm multi-mode |
|------------------------------------|--|
| Cable type (PRS-FINS) | 9/125 µm single-mode |
| Mechanical | |
| Dimensions (H x W x D) | |
| Without bracket | 27 x 243 x 80 mm (1.1 x 9.6 x 3.1 in) |
| With bracket | 34 x 243 x 84 mm (1.3 x 9.6 x 3.3 in) |
| | |

| Weight | 0.7 kg (1.5 lb) |
|----------|--------------------|
| Mounting | Bracket (2 screws) |
| Color | Charcoal |

Environmental

| Operating temperature | -5 °C to +55 °C (+23 °F to +131 °F) |
|-----------------------------------|-------------------------------------|
| Storage and transport temperature | -20 °C to +70 °C (-4 °F to +158 °F) |
| Humidity | 15% to 90% |
| Air pressure | 600 to 1100 hPa |

Ordering information

PRS-FIN Fiber interface

Compact unit with mounting clamp, interface between Praesideo network and a multi-mode glass fiber interconnection to a second fiber interface, powered from Praesideo network. Order number **PRS-FIN**

EWE-PRSFIN-IW 12mths wrty ext Fiber Interface 12 months warranty extension Order number **EWE-PRSFIN-IW**

PRS-FINNA Non-addressable fiber interface Compact unit with mounting clamp, non-addressable interface between Praesideo network and a multimode glass fiber interconnection to a second fiber interface, powered from Praesideo network. Order number **PRS-FINNA**

EWE-PRSFIN-IW 12mths wrty ext Fiber Interface 12 months warranty extension Order number **EWE-PRSFIN-IW**

PRS-FINS Fiber interface single-mode

Compact unit with mounting clamp, interface between the Praesideo network and a single-mode glass fiber interconnection to a second fiber interface, powered from the Praesideo network. Order number **PRS-FINS**

EWE-PRSFIN-IW 12mths wrty ext Fiber Interface 12 months warranty extension Order number **EWE-PRSFIN-IW**

Represented by:

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284 emea.securitysystems@bosch.com emea.boschsecurity.com **Germany:** Bosch Sicherheitssysteme GmbH Robert-Bosch-Ring 5 85630 Grasbrunn Germany www.boschsecurity.com

North America: North America: Bosch Security Systems, LLC 130 Perinton Parkway Fairport, New York, 14450, USA Phone: +1 800 289 0096 Fax: +1 585 223 9180 onlinehelp@us.bosch.com www.boschsecurity.us

Asia-Pacific: Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2699 apr.securitysystems@bosch.com www.boschsecurity.asia

© Bosch Security Systems 2020 | Data subject to change without notice 1874049419 | en, V22, 27. Aug 2020